



pure indoor living



HIGH VELOCITY **AIR CIRCULATOR**

MODEL: BAC015X
BAC016X

INSTRUCTION MANUAL
NOTICE D'UTILISATION
BETRIEBSAN LEITUNG
MANUAL DE INSTRUCCIONES
MANUAL DE INSTRUÇÕES
MANUALE DI ISTRUZIONI
GEBRUIKSAANWIJZING
BRUKSANVISNING
KÄYTTÖOHJE
BRUGSANVISNING

BRUKSANVISNING
NÁVOD K OBSLUZE
NÁVOD NA POUŽITIE
HASZNÁLATI UTASÍTÁS
MANUAL DE UTILIZARE
ИНСТРУКЦИИ ЗА УПОТРЕБА
PRIRUČNIK ZA UPOTREBU
ΕΓΧΕΙΡΙΔΙΟ ΧΡΗΣΗΣ
ИНСТРУКЦИЯ ПО ЭКСПЛУАТАЦИИ
دليل التعليمات

English	4
Français/French	6
Deutsch/German	8
Español/Spanish	10
Português/Portuguese	12
Italiano/Italian	14
Nederlands/Dutch	16
Svenska/Swedish	18
Suomi/Finnish	20
Dansk/Danish	22
Norsk/Norwegian	24
Polski/Polish	26
ČESKY/Czech	28
Slovenčina/Slovakian	30
Magyar/Hungarian	32
Română/Romanian	34
български/Bulgarian	36
Hrvatski/Croatian	38
ΕΛΛΗΝΙΚΑ/Greek	40
РУССКИЙ/Russian	42
العربية / Arabic	45



FIG 1





FIG 2



ENGLISH

PLEASE READ AND SAVE THESE IMPORTANT SAFETY INSTRUCTIONS.

This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.

If the supply cord or plug is damaged, it must be replaced by the manufacturer or its service agent or a similarly qualified person in order to avoid hazard.

- Unplug from the electrical outlet when not in use, when moving the fan from one location to another, before putting on or taking off any parts and before cleaning.
- To protect against electrical shock, do not immerse the appliance, plug or cord in water or spray with liquids.
- Avoid contact with any moving parts.
- Do not operate in the presence of explosive and/or flammable fumes.
- To avoid fire hazard, NEVER place the cord under rugs or any parts near an open flame, cooking or other heating appliance.
- Do not use outdoors.
- Do not let the cord hang over the edge of a table or counter, or come into contact with hot surfaces.
- To disconnect from the electrical supply, grip the plug and pull from the wall outlet. DO NOT pull on the cord.
- This product is intended for household use ONLY and not for commercial or industrial applications.

PARTS

- A** Carrying handle
- B** Speed control
- C** Cord storage
- D** Wall mounting bracket

OPERATING INSTRUCTIONS

Before plugging in the unit, fully unwind the power cord.

1. Set your fan on a dry, level surface.
2. Make sure the speed control is in the OFF position (**0**) then plug in the power cord.

This high quality air circulator features a speed control which allows you to select the desired amount of air and its velocity. Settings are as follows:

1 = Low **2** = Medium **3** = High **0** = OFF

Air circulators can be used alone or in conjunction with an air conditioning unit to circulate the cooled air or to force the air into other rooms. During summer months, your portable air circulator can be used to pick up the cooled air at floor level and circulate it throughout the entire room.

During the winter months your air circulator may be used to enhance the distribution of heated air in your home.

WALL MOUNTING

Your fan is supplied with a mounting bracket **D** which allows you to mount it onto a wall only.

Due to the many different types of mounting surface, mounting screws and fixings are not included with this product.

1. Use the bracket **D** as a template to mark the position of the holes to be drilled (figure 2). Ensure that the position you choose is suitable for mounting and supporting the fan and that the area for fixing is away from any hidden electrical cables or pipes.
2. Drill the holes and fix the bracket to the wall using appropriate hardware.
3. Hook the base of the fan onto the wall bracket as shown (figure 2).

CLEANING

- Always unplug the fan before cleaning.
- Do not allow water to drip onto or into the fan or motor housing.

STORAGE

Store your fan in a safe, dry location away from dust. We strongly recommend using the original box.

TECHNICAL SPECIFICATION

For all Technical and Regulatory information with regards to your product specifications under Eco-Design Regulation No 206/2012, please contact our consumer help line or visit www.bionaireuk.co.uk.

GUARANTEE

Please keep your receipt as this will be required for any claims under this guarantee.

This appliance is guaranteed for 5 years after your purchase as described in this document.

During this guaranteed period, if in the unlikely event the appliance no longer functions due to a design or manufacturing fault, please take it back to the place of purchase, with your till receipt and a copy of this guarantee.

The rights and benefits under this guarantee are additional to your statutory rights, which are not affected by this guarantee. Only Jarden Consumer Solutions (Europe) Limited ("JCS (Europe)") has the right to change these terms.

JCS (Europe) undertakes within the guarantee period to repair or replace the appliance, or any part of appliance found to be not working properly free of charge provided that:

- you promptly notify the place of purchase or JCS (Europe) of the problem; and
- the appliance has not been altered in any way or subjected to damage, misuse, abuse, repair or alteration by a person other than a person authorised by JCS (Europe).

Faults that occur through, improper use, damage, abuse, use with incorrect voltage, acts of nature, events beyond the control of JCS (Europe), repair or alteration by a person other than a person authorised by JCS (Europe) or failure to follow instructions for use are not covered by this guarantee. Additionally, normal wear and tear, including, but not limited to, minor discoloration and scratches are not covered by this guarantee.

The rights under this guarantee shall only apply to the original purchaser and shall not extend to commercial or communal use.

If your appliance includes a country-specific guarantee or warranty insert please refer to the terms and conditions of such guarantee or warranty in place of this guarantee or contact your local authorized dealer for more information.

Waste electrical products should not be disposed of with Household waste. Please recycle where facilities exist. E-mail us at enquiresEurope@jardens.com for further recycling and WEEE information.

Jarden Consumer Solutions (Europe) Limited
5400 Lakeside
Cheadle Royal Business Park
Cheadle
SK8 3GQ
UK



FOR U.K. AND IRELAND ONLY


WARNING - THIS APPLIANCE MUST BE EARTHED

If the plug is not suitable for the socket outlets in your home, it can be removed and replaced by a plug of the correct type.

If the fuse in a moulded plug needs to be changed, the fuse cover must be refitted. The appliance must not be used without the fuse cover fitted.

If the plug is unsuitable, it should be dismantled and removed from the supply cord and an appropriate plug fitted as detailed. If you remove the plug it must not be connected to a 13 amp socket and the plug must be disposed of immediately.

If the terminals in the plug are not marked or if you are unsure about the installation of the plug please contact a qualified electrician.





**Jarden Consumer Solutions (Europe) Limited
Cheadle Royal Business Park, Cheadle SK8 3GQ
United Kingdom**

**Fax: +44 (0)161 626 0391
Email: enquiriesEurope@jardencs.com**

**www.bionaireeurope.com
UK - Free phone Customer Service Helpline – 0800 052 3615**

**Jarden Consumer Solutions (Europe) Limited
420, Rue d'Estiennes d'Orves
Colombes
92700 France
Phone: +33 1 49 64 20 60**

FRANCE - SERVICE CONSOMMATEURS

► N° Indigo 0 825 85 85 82

Belgium:	+32 38 70 86 86
Czech Republic:	+420 48 513 03 03
Finland:	+358 98 70 870
Germany:	+49 89 5480195-0
Hungary:	+36 1 37 17 970
Latvia	+371 7514081
Lithuania	+370 (52) 772388
Netherlands:	+31 793 41 77 71
Poland:	+48 22 847 8968
Russia:	+7 095 334 82 21
Slovakia:	+421 41 723 47 09
Spain:	+34 902 051 045



© 2014 Jarden Consumer Solutions (Europe) Limited.

All rights reserved. Imported and distributed by Jarden Consumer Solutions (Europe) Limited, Cheadle Royal Business Park, Cheadle SK8 3GQ, United Kingdom.

Jarden Consumer Solutions (Europe) Limited is a subsidiary of Jarden Corporation (NYSE: JAH).
The product supplied may differ slightly from the one illustrated due to continuing product development.

Printed In China

Tous droits réservés. Distribué par Jarden Consumer Solutions (Europe) Limited, Cheadle Royal Business Park, Cheadle, SK8 3GQ United Kingdom.
Jarden Consumer Solutions (Europe) Limited est une filiale de Jarden Corporation (NYSE: JAH).

En raison du développement continu de nos produits, le produit livré risque de varier légèrement de l'illustration.

Imprimé en Chine